


AIR CONDITIONING CONTROLS

To preserve energy during the Summer A/C units in all unoccupied units are turned off. If the A/C is off when you move into your new unit, we advise you promptly locate and turn on the unit to begin cooling

Button Panel

To start AC, push the Override button. It will initiate the system for 30 min increments, up to 4 hours, which you will see in the upper left display.

Front Panel



Press the UP or DOWN buttons to adjust both the heat and cool temperatures.



Adjust the desired set temperature with the buttons.



Touch Screen Panel

During the Summer all digital panels are programmed as unoccupied. This can be overridden by using the OVERRIDE button.

Press the “OVERRIDE” button, a screen will appear allowing the user to choose from 30 minute intervals up to 4 hours. This will then start cooling or heating.

To turn off the override timer press the “OVERRIDE” button and when the next screen appears press CANCEL “OVERRIDE”.



During the semester A/C units will be programmed as occupied. Allowing users to simply press the “Warmer” or “Cooler” arrows to set unit temperature.

Pressing the “OVERRIDE” button when the system is set to occupied will force the thermostat into it's unoccupied setting for the rest of the day. If this happens you will then need to operate the system as described above using the “OVERRIDE” button.

Wall Units

Lancer Arms, Point, & Tower Hall all feature wall mounted A/C units. Which will all be operated manually using heating & cooling buttons located on each unit.

Simmons & Smith

The central A/C for Simmons & Smith is centrally controlled to ensure a comfortable temperature throughout the building.

If you run into issues operating your air condition unit, contact the Office of Residence Life & Housing (951) 552-8111